





IMPORTANT

Weatheradio with Alert

Cat. No. 12-251

If a single dash appears on your Weatherradio's display after initial setup, you must re-program the broadcast frequency and FIPS codes. This might occur if AC power is disconnected and backup battery power is low (for example, after a power outage). Follow the instructions in "Programming the Weatherradio" on Page 16 of your Owner's Manual.






© 2000 Tandy Corporation. All Rights Reserved.
RadioShack and RadioShack.com are trademarks used by Tandy Corporation.

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

05A00

Printed in China





© 1999 Tandy Corporation.
All Rights Reserved.
RadioShack is a registered trademark used by Tandy Corporation.

